

## INSTALLATION RECOMMENDATIONS FOR DELMO SPEED 67-72 CHEVY C10 EXTERIOR DOOR HANDLES

### Included Parts List:

- (1) Driver Side Door Handle
- (1) Passenger Side Door Handle
- (2) Buttons
- (2) (2) Cam return springs
- (4 sets) Handle hardware

**\*\*Important Note: Due to the age of the vehicle and wear & tear of daily use, some parts may require extra adjustment or extra steps may be required to insure correct fitment.\*\***

**Step 1** - Remove interior door panel (Pic 1)



Pic 1

**Step 2** - Remove 2 bolts holding the exterior door handle thru 2 access points (Pic 2)



Pic 2

**Step 3** - Due to the extended use of the door handles it might be necessary to trim the rod on the billet handle button or bend the factory lever for proper operation. (Pic 3 & 4)



Pic 3



Pic 4

**Step 4** - Test handles for proper operation prior to installing door panels and

trim.